Effective January 2021 Superseds November 2019

## BUSSMANN SERIES

## **Fuse Accessory Selection Guide**

		4					
	Fuse Family	Size	PCB Fuse Clip	PCB Mount Holder	Panel Mount Holder	In-Line Fuse Holder	Fuse Block
3 3	ABC AGC	1/4" x 1 1/4"	<u>1Axxxx</u>	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HRK HEB HEF HEF HEB HEB HEJ	<u>S-8000</u>
	AGA	1/4" x 5/8"	<u>1Axxxx</u>	-	-	-	-
	<u>AGW</u>	1/4" x 7/8"	<u>1Axxxx</u>	-	-	HRK HHB	-
	AGX	1/4" x 1"	<u>1Axxxx</u>	-	HJL	HRK HHB HHI	3828-1
	<u>ATC</u>	Auto Blade Fuse	<u>1A5600</u> 1A5780	-	-	<u>HHF-JFCU</u>	-
	ATM	Auto Blade Fuse	<u>1A5778</u> <u>1A5779</u>	-	-	HHM	-
Si veo sinè 📻	<u>C519</u>	5 mm x 15 mm	<u>1Axxxx</u>	-	-	HHT	
	<u>C520</u>	5 mm x 15 mm	<u>1Axxxx</u>	-	-	HHT	-
	FNM FNQ	13/32" x 1 1/2"	<u>1A3400</u>	-	HPG	HEB	<u>BMM603</u>
	<u>FNQ-R</u> KTK-R LP-CC	13/32" x 1 1/2"	<u>1A3400</u>	-	<u>HPG</u>	-	<u>BCM603</u>
	<u>FWH/5</u>	1/4" x 1 1/4"	<u>1Axxxx</u>	<u>HBH-I</u> <u>HBV-I</u>	<u>HVP</u>	HVI	<u>S-8000</u>
	GBA GLD	1/4" x 1 1/4"	<u>1Axxxx</u>	-	HLD	-	<u>S-8000</u>
	<u>GBB</u>	1/4" x 1 1/4"	<u>1Axxxx</u>	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HRK HHB HH HH HH HHB HHB HHJ	<u>S-8000</u>
AND A DECEMBER OF	GDA GDB GDC	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> <u>HBH-M</u> <u>HBV-M</u>	HTB	HHT	HTC-15M HTC-60M HTC-78M
	GMA	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> <u>HBH-M</u> <u>HBV-M</u>	<u>HTB</u>	HHT	HTC-15M HTC-60M HTC-78M
-	GMC	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> <u>HBH-M</u> <u>HBV-M</u>	HTB	HHT	HTC-15M HTC-60M HTC-78M
	<u>GMD</u>	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> HBH-M HBV-M	HTB	HHT	<u>HTC-15M</u> <u>HTC-60M</u> <u>HTC-78M</u>



## Fuse Accessory Selection Guide

	Fuse Family	Size	PCB Fuse Clip	PCB Mount Holder	Panel Mount Holder	In-Line Fuse Holder	Fuse Block
	<u>KLM</u> <u>KTK</u>	13/32" x 1 1/2"	<u>1A3400</u>	-	<u>HPG</u>	HEB	<u>BMM603</u>
2 2	MDA MDL MDQ	1/4" x 1 1/4"	<u>1Axxxx</u>	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HEK HEB HEA HEA HEB HEB HEB HEB HEB HEB HEB HEB HEB HEB	<u>S-8000</u>
BUSS S	<u>MDH</u>	1/4" x 1 1/4"	<u>1Axxxx</u>	HBH-I HBV-I	HTB HK HKP HMR HGA-C	王 王 王 王 王 王 王 王 王 王 王 王 王 王 王 王 王 王 王	<u>S-8000</u>
	<u>PCTron</u>	-	-	BK-PCS	-	-	-
	<u>S500</u> <u>S501</u>	5 mm x 20 mm	<u>1Axxxx</u> HTC-2xxM	<u>H15</u> HBH-M HBV-M	HTB	HHT	HTC-15M HTC-60M HTC-78M
	<u>S505</u> <u>S506</u>	5 mm x 20 mm	<u>1Axxxx</u> HTC-2xxM	<u>H15</u> HBH-M HBV-M	HTB	HHT	HTC-15M HTC-60M HTC-78M
	<u>SC-1 to 15A</u>	13/32" x 1.31"	<u>1A3400</u>	-	HPS-EE	HEG	<u>BG3011PO</u>
	<u>SC-20A</u>	13/32" x 1.41"	<u>1A3400</u>	-	<u>HPS-JJ</u>	<u>HEH</u>	<u>BG3011PO</u>
	<u>SC-25 to 30A</u>	13/32" x 1.62"	<u>1A3400</u>	-	HPS-FF	<u>HEC</u>	<u>BG3011PO</u>
	<u>SC-35 to 60A</u>	13/32" x 2 1/4"	<u>1A3400</u>	-	-	HEJ	<u>G30060-1CR</u>
	<u>SFE</u>	1/4" x various lengths (5/8" to 1 7/16")	<u>1Axxxx</u>	-	-	<u>HR/HM</u>	-
	<u>SR-5 / SR-5F / SR-5H</u> <u>SS-5 / SS-5F / SR-5H</u>	-	-	<u>BK-PCS</u>	-	-	-
	<u>TDC10/11</u>	1/4" x 1 1/4"	<u>1Axxxx</u>	HBH-I HBV-I	HTB HK HKP HMR HGA-C	HEK HEB HEA HEE HEB HEB HEB	<u>S-8000</u>
Bussmann b 3A	<u>TDC180</u> TDC600	1/4" x 1"	<u>1Axxxx</u>	-	<u>HJL</u> HJM	HRK HHB HHI	3828-1
3012/00 2012/00 2012/01	<u>TCP70</u>	1/4" x 1"	<u>1Axxxx</u>	-	<u>HJL</u> HJM	HRK HHB HHI	3828-1

**Tools & resources** 

- <u>Webpage</u>
- Parametric search tool
- How to select a fuse holder white paper

Eaton Electronics Division 1000 Eaton Boulevard Cleveland, OH 44122 United States www.eaton.com/electronics

© 2019 Eaton All Rights Reserved Printed in USA Publication No. 10575 BU-MC16086 November 2019

F-T-N Powering Business Worldwide Eaton is a registered trademark.

All other trademarks are property of their respective owners.