SIEMENS

Data sheet

3RA2220-1GH24-0AP0



Load feeder fuseless, Reversing duty 400 V AC, Size S0 4.50...6.30 A 230 V AC Spring-type terminal for 60 mm busbar systems (also fulfills type of coordination 1) Type of coordination 2, Iq = 150 kA 1 NO+1 NC (contactor)

product brand name product designation design of the product	SIRIUS Reversing starter
design of the product	Reversing starter
	for 60 mm busbars
product type designation	3RA22
manufacturer's article number	
 of the supplied contactor 	<u>3RT2024-2AP00</u>
 of the supplied circuit-breakers 	<u>3RV2021-1GA20</u>
 of the supplied RS assembly kit 	<u>8US1250-5AT10</u>
 of the supplied busbar adapter 	<u>8US1251-5NT11</u>
 of the supplied link module 	3RA2921-2AA00
General technical data	
size of the circuit-breaker	SO
size of load feeder	SO
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (switching cycles) of contactor typical	10 000 000
type of assignment	2
type of protection according to ATEX directive 2014/34/EU	Ex II (2) GD
certificate of suitability according to ATEX directive 2014/34/EU	DMT 02 ATEX F 001
Substance Prohibitance (Date)	03/01/2017
Ambient conditions	
ambient temperature	
during operation	-20 +60 °C
 during storage 	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current-dependent overload release	4.5 6.3 A
operating voltage	
rated value	690 V

 at AC-3 rated value maximum 	690 V
operating frequency rated value	50 60 Hz
operational current at AC-3 at 400 V rated value	4.9 A
operating power at AC-3	1.07
at 400 V rated value	2 200 W
Control circuit/ Control	
type of voltage of the control supply voltage	AC
control supply voltage at AC	
• at 50 Hz rated value	230 V
at 50 Hz rated value	230 230 V
apparent holding power of magnet coil at AC	8.5 VA
Auxiliary circuit	
product extension auxiliary switch	Yes
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
UL/CSA ratings	· · ·
full-load current (FLA) for 3-phase AC motor	
• at 480 V rated value	4.8 A
yielded mechanical performance [hp]	
for 3-phase AC motor	
— at 200/208 V rated value	1 hp
— at 220/230 V rated value	1.5 hp
— at 460/480 V rated value	3 hp
— at 575/600 V rated value	5 hp
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	
• at 400 V according to IEC 60947-4-1 rated value	150 000 A
Installation/ mounting/ dimensions	
mounting position	vertical
mounting position fastening method	for snapping onto 60 mm busbar systems
mounting position fastening method height	for snapping onto 60 mm busbar systems 260 mm
mounting position fastening method height width	for snapping onto 60 mm busbar systems 260 mm 90 mm
mounting position fastening method height width depth	for snapping onto 60 mm busbar systems 260 mm
mounting position fastening method height width depth required spacing	for snapping onto 60 mm busbar systems 260 mm 90 mm
mounting position fastening method height width depth required spacing • for grounded parts	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards • for live parts — upwards — upwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — downwards — backwards — downwards — backwards — upwards — downwards	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — at the side — downwards — at the side — downwards — at the side — upwards — at the side	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards • for live parts — forwards — upwards — at the side — downwards — upwards — upwards — the side — downwards — at the side Connections/ Terminals	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards — backwards — at the side — upwards — backwards — the side Connections/ Terminals type of electrical connection	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — backwards — upwards — forwards — backwards — other side Connections/ Terminals type of electrical connection • for main current circuit	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — a the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards • for live parts — forwards — ownwards — upwards — ownwards — for wards — backwards — upwards — for ive parts — forwards — backwards — upwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards • for live parts — forwards — at the side — downwards — backwards — upwards — backwards — backwards — for reads — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data B10 value with high demand rate according to SN 31920	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — downwards • for live parts — forwards — upwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data B10 value with high demand rate according to SN 31920 proportion of dangerous failures	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 0000
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — backwards — downwards — forwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data B10 value with high demand rate according to SN 31920 proportion of dangerous failures • with high demand rate according to SN 31920	for snapping onto 60 mm busbar systems 260 mm 90 mm 165 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 0000 10 000

PROFINET IO	protocol	No			
PROFIsafe pro		No No			
	AS-Interface protocol	INO			
ertificates/ approva	15				
General Product A	pproval			For use in hazard- ous locations	Declaration of Conformity
SP CM	<u>Confirmation</u>		EHC	X ATEX	CE EG-Konf.
Declaration of Conformity	Test Certificates		Marine / Shipping		
UK CA	Special Test Certific- ate	<u>Type Test Certific-</u> ates/Test Report	ABS	B U R E A U VERITAS	Hoyd's Register Lirs
Marine / Shipping				other	Railway
PRS	RINA	RMRS RMRS	DNV-GL DNV-GL	<u>Confirmation</u>	Vibration and Shock
urther information					
https://www.siemens Industry Mall (Onlin	ie ordering system) siemens.com/mall/en/en/ or	Catalog/product?mlfb=	3RA2220-1GH24-0APC ?lang=en&mlfb=3RA222)		

last modified:

2/16/2022 🖸