SIEMENS

Data sheet

3RA2210-1FD15-2BB4




Load feeder fuseless, Reversing duty 400 V AC, Size S00 3.50...5.00 A 24 V DC screw terminal for 60 mm busbar systems Type of coordination 1, Iq = 150 kA 1 NC (contactor)

product brand name	SIRIUS
product designation	Reversing starter
design of the product	for 60 mm busbars
product type designation	3RA22
manufacturer's article number	
 of the supplied contactor 	<u>3RT2015-1BB42</u>
 of the supplied circuit-breakers 	<u>3RV2011-1FA10</u>
 of the supplied RS assembly kit 	8US1250-5AS10
 of the supplied busbar adapter 	8US1251-5DS10
 of the supplied link module 	<u>3RA1921-1DA00</u>
General technical data	
size of the circuit-breaker	S00
size of load feeder	S00
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (switching cycles) of contactor typical	30 000 000
type of assignment	1
type of protection according to ATEX directive 2014/34/EU	Ex II (2) GD
certificate of suitability according to ATEX directive 2014/34/EU	DMT 02 ATEX F 001
Substance Prohibitance (Date)	10/01/2009
Ambient conditions	
ambient temperature	
 during operation 	-20 +60 °C
 during storage 	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current-dependent overload release	3.5 5 A
operating voltage	
 rated value 	690 V

• at AC 3 rated value maximum	690 V
at AC-3 rated value maximum	50 60 Hz
operating frequency rated value operational current at AC-3 at 400 V rated value	3.6 A
operating power at AC-3	5.0 A
at 400 V rated value	1 500 W
Control circuit/ Control	1 300 W
	DC
type of voltage of the control supply voltage control supply voltage at DC	
rated value	24 V
rated value	24 24 V
holding power of magnet coil at DC	4 W
Auxiliary circuit	· · ·
product extension auxiliary switch	Yes
Protective and monitoring functions	
	CLASS 10
trip class design of the overload release	
-	thermal (bimetallic)
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	4.9.4
at 480 V rated value	4.8 A
yielded mechanical performance [hp]	
for 3-phase AC motor at 200/208 V roted value	1 hn
— at 200/208 V rated value — at 220/230 V rated value	1 hp
	1 hp
— at 460/480 V rated value — at 575/600 V rated value	3 hp 3 hp
	5 lip
Short-circuit protection	Vec
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	150 000 A
at 400 V according to IEC 60947-4-1 rated value	100 000 A
Installation/ mounting/ dimensions	
Installation/ mounting/ dimensions mounting position	vertical
Installation/ mounting/ dimensions mounting position fastening method	vertical for snapping onto 60 mm busbar systems
Installation/ mounting/ dimensions mounting position fastening method height	vertical for snapping onto 60 mm busbar systems 200 mm
Installation/ mounting/ dimensions mounting position fastening method height width	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth	vertical for snapping onto 60 mm busbar systems 200 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — forwards — backwards — downwards • for live parts — forwards — backwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — forwards — downwards • for live parts — forwards — backwards — upwards — upwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — forwards — backwards — downwards • for live parts — forwards — backwards	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards — at the side — downwards — at the side — at the side — at the side — at the side	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 32 mm 10 mm 310 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — oforwards — oforwards — downwards — at the side — downwards — at the side	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 32 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — backwards — downwards — at the side — downwards — at the side	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 10 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — downwards — at the side — downwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — downwards — at the side — downwards — at the side — downwards — at the side — downwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 10 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — downwards — at the side — downwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — downwards — at the side — downwards — at the side — downwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections • for main contacts	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — downwards — at the side — downwards — at the side — downwards — at the side — downwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit type of connectable conductor cross-sections • for main contacts — stranded	vertical for snapping onto 60 mm busbar systems 200 mm 90 mm 156 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm

Safety related data						
B10 value with high demand rate according to SN 31920			1 000 000			
proportion of dangerous failures						
• • •	 with high demand rate according to SN 31920 		73 %			
	touch protection on the front according to IEC 60529		finger-safe, for vertical contact from the front			
-	Communication/ Protocol					
protocol is support						
PROFINET IO			No			
PROFIsafe protocol			No			
protocol is supported AS-Interface protocol			No			
Certificates/ approva	lls					
General Product A	pproval				For use in hazard- ous locations	Declaration of Conformity
SP Sm	<u>Confirmation</u>	(ال س		EHC	K ATEX	UK CA
Declaration of Conformity	Test Certificates			Marine / Shipping		
CE EG-Konf.	<u>Special Test Certific-</u> <u>ate</u>	<u>Type Test Cer</u> ates/Test Re		ABS	BUREAU VERITAS	Lloyd's Register uts
Manina / Okimui					- 41	Railway
Marine / Shipping					other	ixanway
Warine / Shipping	RINA	KMRS RMRS		DNV-GL	other	Vibration and Shock
Marine / Shipping	RINA	RMRS		DIVUGL		
PRS	RINA	RMAN		ENVILCONS		-
PRS Dangerous Good Transport Informa- tion	RINA	EXAMPLE		UNV-GL ENVELCOMEN		-
Dangerous Good Transport Informa- tion Eurther information Information- and Do https://www.siemenss Industry Mall (Onlin https://mall.industry.si Cax online generato http://support.automa Service&Support (M	ne ordering system) siemens.com/mall/en/en/ or ation.siemens.com/WW/(Manuals, Certificates, C	Catalog/product CAXorder/defaul haracteristics,	<u>t?mlfb=</u> lt.aspx? FAQs,	3RA2210-1FD15-2BB4 2lang=en&mlfb=3RA222)	Confirmation	-
Dangerous Good Transport Informa- tion Eurther information Information- and Do https://www.siemens Industry Mall (Onlin https://mall.industry.si Cax online generato http://support.automa Service&Support (M https://support.industionality/support.industi	s.com/ic10 ne ordering system) siemens.com/mall/en/en/ or ation.siemens.com/WW/Q Manuals, Certificates, C try.siemens.com/cs/ww/e roduct images, 2D dime on.siemens.com/bilddb/ca	Catalog/product CAXorder/defaul haracteristics, n/ps/3RA2210- nsion drawing: ax_de.aspx?mlfl	t?mlfb= lt.aspx? FAQs, 1FD15- s, 3D m b=3RA2	3RA2210-1FD15-2BB4 Plang=en&mlfb=3RA22) 2BB4 nodels, device circuit (2210-1FD15-2BB4&land	Confirmation	Vibration and Shock
Dangerous Good Transport Information Information- and Do https://www.siemenss Industry Mall (Online thtps://www.siemenss Industry Mall (Online thtps://www.siemenss Industry Mall (Online thtps://support.automation-automation-automaticetocoments Service&Support (M https://support.automaticetocoments Service&Support (M https://support.indust Image database (pr https://support.indust Further characteris	s.com/ic10 siemens.com/mall/en/en/ or ation.siemens.com/WW/Q Manuals, Certificates, C try.siemens.com/cs/ww/e roduct images, 2D dime	Catalog/product CAXorder/defaul haracteristics, n/ps/3RA2210- nsion drawing: ax_de.aspx?mlft t, Let-through c n/ps/3RA2210- urance, switchi	t?mlfb= FAQs, FAQs, 1FD15- s, 3D m b=3RA2 current 1FD15- ing free	3RA2210-1FD15-2BB4 2lang=en&mlfb=3RA221) 2BB4 nodels, device circuit of 2210-1FD15-2BB4&land 2210-1FD15-2BB4&land 2BB4/char guency)	Confirmation	Vibration and Shock



last modified:

2/16/2022 🖸